





VERSION 1.4 | 10 JUNE 2014



ANRP 3010



Document Control

Identification

Document Title	Number	Version	Date
ANRP 3010 USING A TRACK WORK AUTHORITY	1.0	Approved	03 March 2009
ANRP 3010 USING A TRACK WORK AUTHORITY	1.1	Approved	04 May 2009
ANRP 3010 USING A TRACK WORK AUTHORITY	1.2	Approved	16 March 2011
ANRP 3010 USING A TRACK WORK AUTHORITY	1.3	Approved	20 March 2013
ANRP 3010 USING A TRACK WORK AUTHORITY	1.4	Approved	10 June 2014

Document History

Publication Version	Effective Date	Page(s) Affected	Reasons for and Extent of Change(s)
VERSION 1.0	03 March 2009	ALL	Approval to issue
VERSION 1.1	04 May 2009	Various	Approval to issue
VERSION 1.2	16 March 2011	4, 5, 6, 7, 8, 9, 10, 12, 14, 16, 17, 18, 19 of 19	Amendment number 1
VERSION 1.3	20 March 2013	2, 5, 6, 15, 16, 17, 19 of 20	Amendment number 3
VERSION 1.4	10 June 2014	2, 5 of 20	Amendment number 4

Authorisation

KB Taylor CEO RISSB 10 June 2014

Distribution and Change

The RISSB maintains the master for this document and publishes the current version on the RISSB website. Any changes to the content of this publication require the version number to be updated. Changes to this publication must be approved according to the procedure for developing RISSB products. The electronic content of the document is available to Rail Infrastructure Manager at any time providing the access agreement with RISSB is signed.



Contents

1	Introduction	5
2	Obtaining a Track Work Authority	5
3	Jointly with a Track Occupancy Authority (TOA)	6
4	Protecting worksites	7
5	Managing signals affected by work on track	7
,	Where handsignallers are used	7
,	Where handsignallers are not used	7
6	Managing rail traffic approaches to worksites	8
ı	Using handsignallers	8
ı	Using signs	8
7	Protecting worksites using handsignallers only	8
8	Protecting worksites using STOP AHEAD and STOP signs only	9
9	Protecting worksites using a handsignaller or signs at a staff hut	9
;	Staff hut located more than 1000m and less than 2500m from the worksite	10
10	Protecting worksites using handsignallers or STOP signs at protecting signals	11
;	Signals between 200m and 500m from the worksite	11
;	Signals more than 500m from the worksite	11
11	Protecting worksites using handsignallers at protecting signals	11
;	Signals between 500m and 1000m from the worksite	11
	Signals more than 1000m and less than 3000m from the worksite	13
	At least two controlled absolute signals within 500m of the worksite	14
12	Protecting a worksite using a handsignaller at a single line crossing location	14
13	Managing rail traffic transits through worksites using handsignallers	15
14	Managing rail traffic transit through worksites using signs	17
15	Rail traffic clearing worksites	18



16 and ca	Using clearance handsignallers if controlled absolute signals are used to protect the worksing the cleared	te 18
17 cannot	Using clearance handsignallers if permissive signals are used to protect the worksite and the cleared	19
18	Returning the track to service	19
19	Keeping records	20
20	ANRP reference	20
21	Effective date	20